


A-FRAME BANNER INSTALLATION

STEP 1

ASSEMBLE THE ULTIMATE A-FRAME™

Unfold Ultimate A-Frame in the shape of the triangle, with the smallest side on the floor (the velcro will be at the bottom parallel to the ground). Fold wings in toward the center until the notch rests in the ridge in the middle.



STEP 3

PLACE YOUR BANNER ON THE ULTIMATE A-FRAME

Line up velcro edge of banner at bottom of Ultimate A-Frame and attach to velcro. Wrap around the banner to the other side and attach remaining velcro edge to bottom strip of the other side of the Ultimate A-Frame.



STEP 2

LOCATE YOUR VELCRO ON THE BANNER

Each end of the banner has a strip of velcro. Lay the banner printed side down.



STEP 4

SECURE YOUR ULTIMATE A-FRAME

Secure your Ultimate A-Frame with the included ultralight Aluminum stakes. Designed to not break or bend, your Ultimate A-Frame will stay put until ready to pack up for the event/season. The tapered end makes it easier to stake into the ground.

